

Romwell pallet skids are modern, inexpensive and high-performance load carriers. They can be cemented beneath a box or a format in a matter of seconds: And your mobile shipping unit is ready

To achieve optimal performance, the following points should be observed during processing:

- The pallet skids are delivered stacked on a pallet. The protective paper is pulled off and the pallet skids can be removed. (Fig. 1)
- Do not touch the adhesive lines; protect these against dust and soiling.
- 170 mm to 600 mm long pallet skids are supplied in perforated lengths. The perforation can be separated very easily. To do this, place the skid on a table and break off downwards over the edge. Do not touch the adhesive lines whilst doing this. With a little practice, the skid can also be broken off over your knee. (Fig. 2)
- Before cementing on, check the locations in which the skids are to be applied. Please note the widths and fork gaps of the industrial trucks. Under certain circumstances, the skids may have to be cemented offset. In the case of 600 mm wide boxes, for example, one of the skids is offset inwards by 100 mm. (Fig. 3)
- Position the adhesive side of the pallet skid onto the desired surface on the format or the box. Press on firmly for 3-4 seconds. The highest possible pressure is vital to trigger the bonding process. The position of the skid can then no longer be corrected.
- In the case of boxes which are positioned upside-down, the resistance required to apply a sufficiently high pressure is often lacking. Two steps are possible:
  - 1) When the boxes are filled with packaged materials weighing over 100 kg, the package weight ensures the necessary load.
  - 2) When filled with lighter weights, the box should be placed onto its base with the skids positioned. A load simply has to be applied briefly from the inside of the box in the area of the skids.
- The optimal processing temperature lies between 18°C and 27°C. The bonding process is slower at temperatures below 18°C. Processing should not be carried out at temperatures below 5°C.
- Pallet skids which are not processed should be covered with silicone paper again. This protects the adhesive lines from dust and drying out. The recommended storage conditions correspond to those of boxes.

